



Step-by-step process for Maine Traditions Stain Application

Before use

With the secured lid and fastened clips, shake well before use.

Safely remove (4) clips on the lid of the can.

If buying multiple pints of the same color, it is recommended to mix all the pints thoroughly together.



Applying Stain

1. Apply on clean surface. Stain can be applied with a brush, sponge, rag, or clean cloth. Test stain on a hidden area. Apply the stain generously to the wood. If working with a brush, apply the stain both with and against the grain. Apply the stain in a circular motion if working with a sponge, rag, or clean cloth. Regardless of the method, the goal is to apply an even coat of stain over the entire surface. For best results, stain should be applied to the species of flooring you wish to match.



2. Wait for 5 to 15 minutes before wiping off the excess stain. This will allow the stain to absorb. A longer wait time will cause a darker stain. Wipe off excess in the direction of the wood grain. Wiping in this direction will accent the wood grain in the final product. Thoroughly stir product. The more mixing, the more consistent the product will be time to time.



3. If desired, apply additional coats of stain to deepen the color. Repeat the same application process.



4. Let the wood stain dry in a well-ventilated area for at least 6 to 8 hours before finishing the wood. Suggested to allow stain to dry for 24 hours before applying a protective finish. For the best match to your hardwood floor, pair with a protective finish that has similar sheen level.



Product

Ideal For Use On

Application Tools

Number Of Coats

Time To Recoat

Dry Time

Colors



Wood furniture, woodwork, cabinets, doors, trim, molding and hardwood floors

A brush, sponge, rag, or clean cloth.

1 coat. To darken the color, apply a second coat after 2-4 hours (time dependent on color).

2-4 hours depending on color

2-4 hours depending on color

39 colors found on our site. Mainetraditionsflooring.com

Disclaimer: Maine Traditions Hardwood Flooring / WW Flooring Group is not responsible for color match to our flooring products. The finish on our hardwood flooring is applied with a UV cured process that cannot be replicated on a jobsite or in a home. This stain is developed simple as a tool to provide a close blend color match to our flooring products.

Notes: Keep from freezing. Store below 10.5F. For interior use only. Dry times vary on good ventilation, temperature off 77 F and 50% relative humidity, lack of air movement or application of thick coats will extend drying times. Always test surface for tackiness between coats. Always spot test on an inconspicuous area to ensure satisfactory results.

Warning: Use only adequate ventilation. Open windows and doors or use other means to ensure fresh air entry during application and drying. Wash hands after using. Keep container closed when not in use.

First Aid: In case of eye contact flush thoroughly with large amounts of water for 15 minutes and get medical attention. For skin contact wash thoroughly with soap and water. In case of respiratory difficulty, provide fresh air and call physician. If swallowed call Poison Control Center, hospital emergency room, or physician immediately.

KEEP OUT OF REACH OF CHILDREN.